

# KRETER INTERIOR FLOORING TEXTURE

### WALL FINISH PROFESSIONALS

TAIWAN • MALAYSIA • THAILAND





 Singapore Offices
 62 Ubi Road 1, Oxley Bizhub 2, #01-41, Singapore 408734

 20 Depot Lane #01-05, Singapore 109763
 t. +65 6926 2610

 m. +65 8788 6890 (WhatsApp only)

alaysia Offices Unit A-01-24, Plaza Bukit Jalil (Aurora Place), No. 1, Persiaran Jalil 1, Bandar Bukit Jalil, 57000 Kuala Lumpur Malaysia

57000 Kuala Lumpur Malaysia JB1: 6 Jalan Ekoperniagaan 1/28, Taman Ekoperniagaan, 81100 Johor Bahru, Johor, Malaysia

JB2: 27 Jalan Ekoperniagaan 2/7, Taman Ekoperniagaan, 81100 Johor Bahru, Johor, Malaysia

t. +60 7511 4788 m. +60 11 7019 0428 (WhatsApp only)

\* Photos of the products shown in this catalogue may vary in color due to lighting condition & printing. We suggest you examine actual product samples before ordering.



UKAS

UKAS

KRETERRA-E01-2112



# KRETERRA

Due to the popular demand of cement render texture, we bring you - **Kreterra**. Kreterra is a cement effect floor coating which can bring you the industrial and minimalistic effect without the problem of cracking and chipping off - usually caused by normal cement render.



Low VOC & Odor



Formaldehyde & Lead Free



Water Based & Eco-friendly




Anti-chalking & Efflorescence



Easy Maintenance



Easy to Touch Up






Shark Grey | KRT-703






Granite Grey | **KRT-704** 









All color shown are as close to the actual SUZUKA® Kreterra colors as modern printing techniques permit. Color appearance/finishing may vary according to amount of coats, style of strokes applied and individual painting methods.

# KRETERRA APPLICATION TECHNIQUES

SUBSTRATE REQUIREMENT & PREPARATION:





Grind the floor to ensure a rough surface for moisture barrier application.

> Spread the mixed MB with flat/notch trowel to the required thickness. Immediately after, use the spike roller to remove entrapped air and to ensure the uniform thickness.



**STEP 3 : SANDING** 

After the surface dried for **24 hours**, sand the surface with sandpaper (7 grit) to ensure a smooth surface. Remove the dust & the dirt from the surface.





After the surface dried, sand the surface with sandpaper (7 grit) to ensure a smooth surface. Remove the dust & the dirt from the surface.

#### TOOLS :





Trowel

V-notch Trowel

Let it fully dry for **14 hours**.

## **COATING SYSTEM**

	Material	(Weight Ratio)	of Coats	Interval (Hrs)	Consumption	TOOIS	
1	Moisture Barrier EP-MB Self Smoothening Epoxy Cementitious Moisture Barrier	Part A : 3.5 kg Part B : 1.5 kg Part C : 19 kg	1	24 Hours	2 kg/m² (1 mm)	Trowel, Paint Roller & Spike Roller	
2	Primer KRP - Kreterra Primer	1L	1	4 Hours	7 – 9 m²/ltr	Roller	
3	Texture Coat KRT - Kreterra Texture	1L	1 - 2	2 Hours	5 – 6 m²/ltr	Trowel	
4	Topcoat WPU-G (GLOSS) Water based PU Topcoat	<b>5 KG</b> (4 : 1) Part A : 4 kg Part B : 1 kg	1 - 2	14 Hours	0.13 kg/m² @ 50μ	Spray & Roller	
	<b>WPU-M (MATT)</b> Water based PU Topcoat	<b>5.5 KG</b> (4.5 : 1) Part A : 4.5 kg Part B : 1 kg					



Mix Part A and Part B in 20L pail for 5 seconds, add component C, mix thoroughly for at least 2 minutes using a suitable electrical stirrer with helical paddle (with 750 watt high power mixer) until a smooth homogenous consistency is achieved.



Scrape a layer of texture coat randomly on the entire surface. Let dry for 40 minutes.

A second layer of texture coat may be applied to enhance the texture effects.



STEP 7 : TOPCOAT

Mix Part A & Part B of topcoat. Roll a layer of topcoat on the entire surface. Use a dry and clean roller to absorb the excess topcoat.



APPLICATION VIDEO

